## **Layout & EMI Quick Guide**

- Minimize hot loops (PRI/SR/clamp)
- Short Kelvin sense to sources
- Gate resistor to shape dv/dt
- Thermal vias & copper spreading