

ORing FET Sizing & Thermal Quick Guide

- Estimate V_{FWD} and conduction loss: $P \approx I^2 \cdot R_{DS(on)}$
- Transient & surge: check SOA curves
- Package: copper area & vias for heat-spreading
- Back-to-back FETs for true reverse blocking
- Select sense/drive controller thresholds carefully