

Power-Path / OTG Reference

- Three nodes: ADAPTER (IN), BAT (PACK), SYS (LOAD).
- Priorities: IN→SYS then charge; brown-in/out thresholds → seamless handover.
- OTG: BAT→SYS boost for peripherals; ensure OCP/OTP and reverse blocking.
- Ship/storage mode: FETs off; leakage spec; wake via adapter/KEY pin/host.